



**Step 1** = lowest setting (smallest square)  
**Step 4** = highest setting (biggest square)



	Stone & Wood cleaner	Rattan & Plastic cleaner	Car combi cleaner	Stone Plague cleaner	Stone sealer	Boat cleaner	Bike & motor cycle cleaner	Grill & metal cleaner
Nilfisk High Pressure Washer <b>C 100 - C 120</b>	Step 3 or higher	Step 3 or higher	Step 2 or higher	Step 4	Step 4	Step 2 or higher	Step 2 or higher	Step 3 or higher
Nilfisk High Pressure Washer <b>C 125</b>	Step 3 or higher	Step 3 or higher	Step 2 or higher	Step 4	Step 4	Step 2 or higher	Step 2 or higher	Step 3 or higher
Nilfisk High Pressure Washer <b>C 130.2</b>	Step 3 or higher	Step 3 or higher	Step 2 or higher	Step 4	Step 4	Step 2 or higher	Step 2 or higher	Step 3 or higher
Nilfisk High Pressure Washer <b>C 130.1</b>	Step 3 or higher	Step 3 or higher	Step 3 or higher	Step 4	Step 4	Step 3 or higher	Step 3 or higher	Step 3 or higher
Nilfisk High Pressure Washer <b>D 130, D 140</b>	Step 3 or higher	Step 3 or higher	Step 2 or higher	Step 4	Step 4	Step 2 or higher	Step 2 or higher	Step 3 or higher
Nilfisk High Pressure Washer <b>E 130, E 140, E 145</b>	Step 3 or higher	Step 3 or higher	Step 3 or higher	Step 4	Step 4	Step 3 or higher	Step 3 or higher	Step 3 or higher
Nilfisk High Pressure Washer <b>E 150</b>	Step 3 or higher	Step 3 or higher	Step 3 or higher	Step 4	Step 4	Step 3 or higher	Step 3 or higher	Step 3 or higher